


ERMS

Rotary drive unit

FESTO

Operating instruction



8199405

8199405
2023-11d
[8199407]

Translation of the original instructions

IO-Link is a registered trademark of its respective trademark holder in certain countries.

Table of contents

1	Applicable documents	4
2	Product version	4
3	Safety	4
	3.1 Safety instructions	4
	3.2 Intended use	4
	3.3 Training of qualified personnel	4
4	Additional information	4
5	Product overview	5
	5.1 Scope of delivery	5
	5.2 System overview	5
	5.2.1 Product design	6
	5.3 Function	6
6	Transport	7
7	Assembly	7
	7.1 Safety	7
	7.2 Unpacking	7
	7.3 Mounting rotary drive	7
	7.4 Mounting the attachment component	9
8	Installation	10
9	Commissioning	13
	9.1 Commissioning: DIO operation (digital I/Os)	14
	9.2 Commissioning: IO-Link operation	15
10	Operation	16
	10.1 Master control	16
	10.2 Dimension reference system	16
	10.3 Restart with homing	17
	10.4 HMI display and control elements	19
	10.5 Homing with end position determination	21
	10.6 Point-to-point operating modes	22
11	Maintenance	25
	11.1 Safety	25
	11.2 Cleaning	25
12	Malfunctions	25
	12.1 Fault clearance	28
	12.2 Repair	28
13	Replacement	28
14	Removal	29
15	Technical data	29

1 Applicable documents



All available documents for the product → www.festo.com/sp.

Document	Product
Operating instruction	Integrated drive EMCS-ST
Assembly instructions	Adapter NEFC-M12G8-0.3-M12G5-LK

Tab. 1: Applicable documents for the product

2 Product version

This documentation refers to the following datasets:

- Hardware version of the integrated drive up to "Rev02" or "RevB"
- Firmware version of the integrated drive from "v19.0.4.107_release"
- IO-Link device description file (IODD) from V1.2.6
- Adapter NEFC from production date 01/2022

When using a different firmware version, check whether a corresponding version of the documentation is available → www.festo.com/sp.

3 Safety

3.1 Safety instructions

- Observe the identifications on the product.
- Before working on the product, switch off the power supply and secure it against being switched on again.
- Store the product in a cool, dry environment protected from UV and corrosion. Keep storage times short.
- Observe the tightening torques. Unless otherwise specified, the tolerance is $\pm 20\%$.

3.2 Intended use

The rotary drive unit ERMS positions payloads between two end positions.

3.3 Training of qualified personnel

Work on the product may only be carried out by qualified personnel who can evaluate the work and detect dangers. The qualified personnel have knowledge and experience in dealing with electric drive systems.

4 Additional information

- Contact the regional Festo contact if you have technical problems → www.festo.com.
- Accessories and spare parts → www.festo.com/catalogue.

5 Product overview

5.1 Scope of delivery

The following components are included in the scope of delivery:

- Rotary drive unit ERMS
- Operating instructions for ERMS rotary drive unit
- Adapter for IO-Link operation (optional accessory) → www.festo.com/catalogue

5.2 System overview





Fig. 1: System overview ERMS


5.2.1 Product design



- 1 Hollow shaft for energy through-feed
- 2 Rotary drive ERMS
- 3 Product labelling
- 4 Controller housing
- 5 Integrated drive EMCS-ST
- 6 Warning symbol "Attention! Hot surface"
- 7 Rotating plate
- 8 Thread and centring hole for attachment components
- 9 Thread and centring hole for direct fastening
- 10 Thread for direct fastening

Fig. 2: Product design ERMS

Electrical connections, display elements and HMI control elements



- 1 LED display menu (Speed Out, ..., Demo)
- 2 LED parameter display
- 3 LED C/Q
- 4 Load voltage connection [Power]
- 5 Logic voltage connection and digital I/O or IO-Link connections [Logic]
- 6 Pushbutton actuator (right arrow)
- 7 Pushbutton actuator (Edit)
- 8 Pushbutton actuator (left arrow)

Fig. 3: Electrical connections, display elements and HMI control elements

5.3 Function

The rotary drive unit converts the rotary motion of the attached motor into a rotary motion of the rotating plate. The torque of the motor is transmitted to the rotating plate by the helical gear unit.

6 Transport

NOTICE

Unexpected and unbraked movement of components

- Secure moving components for transport.

Transport conditions and storage conditions

- Store and transport the product in its original packaging.
- Store the product in a cool, dry environment protected from UV and corrosion. Keep storage times short.
- Store product in areas where it is not exposed to oils, greases and degreasing vapours.

7 Assembly

7.1 Safety

WARNING

Risk of injury due to unexpected movement of components.

The drive can move freely in the voltage-free state. This can cause unexpected movements of the connected mechanics and crush parts of the body.

- Bring moving parts of the mechanical system into a safe position.

7.2 Unpacking

1. Open packaging.
2. Remove all transport materials (e.g. foils, caps, cardboard boxes).
3. Remove the product from the packaging and place it on the mounting surface.
4. Dispose of packaging and transport materials.

7.3 Mounting rotary drive


Requirement

- No collision in the range of motion of the attachment component with mounting components.
- No distortion or bending when installing the product.

1. Select mounting attachments → www.festo.com/catalogue.
2. Place the mounting attachments on the support points.
3. Tighten retaining screws.

Observe max. tightening torque and max. screw-in depth.

For additional information, contact your local Festo Service.





Tab. 2: Overview of mounting components

Size	25	32
Direct fastening via thread		
Screw	M6	M8
Max. screw-in depth t_{max}		
front	16	20
bottom, left, right	9.5	15
Max. tightening torque [Nm]	8	24
Centring, bottom, left, right (hole tolerance H7)		
Centring sleeve [mm]	∅ 9	∅ 12
Direct fastening via through-hole		
Hole length [mm]	45.8	39.7
Hole diameter [mm]	5.5	6.6

Tab. 3: Information on mounting attachments


7.4 Mounting the attachment component

Collision-free	Centre of gravity and tilting moment
	

Tab. 4: Requirement for attachment component

Requirement

- No collision in the range of motion of the attachment component with mounting components.
 - Position of the centre of gravity and tilting moment (force F parallel to the axis of rotation) of the attachment component centrally and close to the centre of the rotating plate (short lever arm a).
1. Select accessories → www.festo.com/catalogue.
 2. Place centring components in centring holes.
 3. Position the attachment component on the rotating plate.
 4. Tighten retaining screws.
Observe max. tightening torque and max. screw-in depth.

Direct fastening
<p data-bbox="132 820 319 845">Mounting via thread</p> 

Tab. 5: Overview of attachment component

Size	25	32
Direct fastening		
Screw [mm]	M5	M5
Tightening torque [Nm]	5	5
max. screw-in depth t_{max} [mm]	8.5	10
Centring, 4x (hole tolerance H7)		
Centring sleeve [mm]	∅7	
Hub centring, 1x (hole tolerance H8)		
Centring sleeve [mm]	∅15	∅20

Tab. 6: Information on attachment components

8 Installation

WARNING

Risk of injury due to electric shock.

- For the electrical power supply with extra-low voltages, use only PELV circuits that guarantee a reinforced isolation from the mains network.
- Observe IEC 60204-1/EN 60204-1.

i

Damage to the device due to non-approved potentials at the pins

- Power connection:
 - Do not connect pin 3
- Logic connection:
 - Apply the logic supply [Logic Pin 1] and the IO-Link communication signal C/Q [Pin 3] at least 50 ms after the load supply 24 V DC [Power Pin 1]. For example, ensure the switch-on delay by interposing relay contacts.
 - Disconnect the logic supply [Logic Pin 1] and the IO-Link communication signal C/Q [Pin 3] after a shutdown, after an interruption or before restoring the load supply 24 V DC [Power Pin 1].
 - EMCS-ST is not hot-plug capable: 24V level to the digital outputs DO1/DO2 [Pin 2/3] or the IO-Link communication signal C/Q [Pin 3] only after connecting the reference potentials GND/L– [Pin 4/8].
 - Disconnect the digital outputs DO1/DO2 [Pin 2/3] and the IO-Link communication signal C/Q [Pin 3] at least 50 ms before the power supply connections GND/L– [Pin 4/8] and 24 V DC/L+ Disconnect [Pin 1]. For example, ensure the switch-off delay by interposing relay contacts.
- GND and L– connections:
 - Apply the Power, GND [Pin 2] and Logic, GND/L– [Pin 4/8] connections to one potential. For example, ensure the same potential by using a common fixed power supply or an electrical connection of the two 0 V DC GND potentials.

1. Connect the power cable to the [Power] connection of the integrated drive EMCS-ST and to a PELV fixed power supply.
2. Connect the logic cable to the [Logic] connection of the integrated drive EMCS-ST and to a controller or to a IO-Link master.

Wiring diagram: DIO operation (digital I/O)



In NPN mode defined levels must be applied to the DI1/DI2 digital inputs of the EMCS, e.g. by controller outputs with pull-up resistors (4.3 kΩ recommended).




Fig. 4: Wiring diagram: DIO operation (digital I/O)

- | | |
|--|---|
| <p>1 PELV fixed power supply for the load voltage supply</p> <p>2 PELV fixed power supply for the logic power supply</p> | <p>3 Integrated drive EMCS-ST</p> <p>4 Higher-order controller with digital I/O</p> |
|--|---|

Status and control signals

The following table shows the status and control signals and the electrical levels of the digital inputs and outputs as a function of the "PNP/NPN" version of the integrated drive.

Status and control signal	Electrical levels	
	PNP, positive logic	NPN, negative logic
0	Low level (0 V)	High level (24 V)
1	High level (24 V)	Low level (0 V)

Tab. 7: Overview of status and control signals as a function of electrical levels

Wiring diagram: IO-Link operation

Current consumption of IO-Link power supply [Logic]
 An input current at pin 1 (L+) of 100 ... 150 mA is required for operation.

Connecting IO-Link directly to the master




Fig. 5: Wiring diagram: IO-Link operation

- 1 PELV fixed power supply for the load voltage supply
- 2 PELV fixed power supply for the logic power supply
- 3 Integrated drive EMCS-ST
- 4 IO-Link master with IO-Link interface, port class A

Connecting IO-Link IO-Link to the master via adapter NEFC

Adapter NEFC up to production date 2021
 Adapters NEFC up to production date 2021 can only be used for IO-Link masters with port class A.




Fig. 6: Wiring diagram: IO-Link operation via adapter NEFC

- | | |
|--|---|
| <p>1 PELV fixed power supply for the load voltage supply</p> <p>2 PELV fixed power supply for the logic power supply</p> | <p>3 Integrated drive EMCS-ST</p> <p>4 IO-Link master with IO-Link interface</p> <p>5 Adapter NEFC</p> |
|--|---|

i

Core colours of Festo cables:

BK = black, BN = brown, BU = blue, GN = green, GY = grey, PK = pink, WH = white, YE = yellow

9 Commissioning

⚠ WARNING

Risk of injury due to unexpected movement of components.

- Protect the positioning range from unwanted intervention.
- Keep foreign objects out of the positioning range.
- Perform commissioning with low dynamic response.

⚠ WARNING

Severe, irreversible injuries from accidental movements of the connected actuator technology.

Unintentional movements of the connected actuator technology can result from exchanging the connecting cables of a servo drive or between servo drives.

- Before commissioning: All cables must be correctly assigned and connected.

⚠ WARNING**Danger of burns from hot housing surfaces.**

Metallic housing parts can reach high temperatures during operation.

Contact with metal housing parts can cause burn injuries.

- Do not touch metallic housing parts.
- After the power supply is switched off, let the device cool down to room temperature.

**Update device data only with IO-Link.**

- Updating firmware
- Updating parameter set
- Data backup (Data Storage)

➔ Instruction manual for "Integrated drive EMCS" ➔ www.festo.com/sp

9.1 Commissioning: DIO operation (digital I/Os)

Preparation:

1. Check mounting of the drive system.
2. Check wiring of the power supplies and the "DI/DO" digital inputs and outputs at the [Power] and [Logic] connections.

Procedure:

1. Switch on load voltage.
2. Apply the logic supply [Logic Pin 1] at least 50 ms after the load supply 24 V DC [Power Pin 1]. For example, ensure the switch-on delay by interposing relay contacts.
Disconnect the logic supply [Logic Pin 1] after a shutdown, after an interruption or before restoring the load supply 24 V DC [Power Pin 1].
If the logic voltage is switched on before the load voltage, there is a risk of an irreversible device defect in rare cases.
3. Wait for initialisation until C/Q LED is yellow (≈ 7 s).
4. Select the reference end position "Ref" from the HMI interface in the "Reference" menu and start the homing with end position detection (only required if the reference end position "Ref" is different from the factory setting or if the useful range has been changed). The drive system is referenced after a successful homing.



Referencing sets the start press position "PoS_{Start Press}" equal to the calculated useful range.

5. Parameterisation of operating modes via HMI interface:
Basic parameters for point-to-point operation with and without press function or manual operation (demo)
 - "Speed Out" speed
 - "Speed In" speed
 additional parameters for point-to-point operation with press function
 - "Force"
 - Start Press "PoS_{Start Press}" position (reference point end position "Ref")

The EMCS-ST is then ready for operation and the application can be controlled via the "DI/DO" digital inputs and outputs → 10.6 Point-to-point operating modes.

9.2 Commissioning: IO-Link operation

Preparation

1. Check mounting of the drive system.
2. Check the wiring of the power supplies and the IO-Link "C/Q" interface at the [Power] and [Logic] connections.

Procedure

1. Switch on load voltage.
2. Apply the logic supply [Logic Pin 1] and the IO-Link communication signal C/Q [Pin 3] at least 50 ms after the load supply 24 V DC [Power Pin 1]. For example, ensure the switch-on delay by interposing relay contacts.
Disconnect the logic supply [Logic Pin 1] and the IO-Link communication signal C/Q [Pin 3] after a shutdown, after an interruption or before restoring the load supply 24 V DC [Power Pin 1].
If the logic voltage is switched on before the load voltage, there is a risk of an irreversible device defect in rare cases.
3. Wait for initialisation until C/Q LED is yellow (≈ 7 s).
4. Select the reference end position "Ref" from the IO-Link device data (0x0103.0, reference) and start the homing with end position detection (0x0104.0, Execute "Reference" Movement) (only required if the reference end position Ref" is different from the factory setting or if the useful range has been changed). The drive system is referenced after a successful homing.



Homing sets the "Pos_{Imp}" intermediate position and the "Pos_{Start Press}" start press position equal to the determined useful range.

5. Parameterisation of operating modes via IO-Link interface:
Basic parameters for point-to-point operation with and without press function or manual operation (demo)
 - 0x0100.0, "Speed In" speed
 - 0x0101.0: "Speed Out" speed
 - 0x0106.0, end position "Out" "Lim_{Out}" (reference point reference end position "Ref")
 - 0x0108.0, intermediate position "Pos_{Imp}" (reference point reference end position "Ref")additional parameters for point-to-point operation with press function
 - 0x0102.0, "Force" force
 - 0x0105.0, start press position "Pos_{Start Press}" (reference point reference end position "Ref")

Then the EMCS-ST is ready for operation and the application can be controlled via the IO-Link interface "process data 0x0029.1, 0x0029.2 and 0x0029.5" or "system parameter 0x0002" → 10.6 Point-to-point operating modes.

10 Operation

WARNING

Danger of burns from hot housing surfaces.

Metallic housing parts can reach high temperatures during operation.

Contact with metal housing parts can cause burn injuries.


- Do not touch metallic housing parts.
 - After the power supply is switched off, let the device cool down to room temperature.
-

10.1 Master control

- Lowest priority: DIO operation (after Power ON and initialisation)
- Medium priority: IO-Link operation (after established IO-Link communication)
- Highest priority: HMI operation (unlocked pushbutton actuators)

10.2 Dimension reference system

The correct positioning of the drive requires a defined dimension reference system.



Tab. 8: Dimension reference system for rotary drive systems

10.3 Restart with homing

Re-initialise reference end position "Ref"


The referencing of the reference end position is lost on Power OFF of the logic voltage L₊ [Logic, Pin 1]. After every restart the position of the reference end position "Ref" is re-initialised at the "Speed Ref" velocity with the first motion task.

Homing after a restart as a function of the positioning task


Sequence

- Mov_{Ref}: force-controlled movement Ctrl_f → against mechanical stop "Mech_{in}"
- Mov_{Out}: position-controlled movement Ctrl_p → to the reference end position "Ref"
- Travel to the target position as a function of the positioning task
 - No travel, end position "Lim_{in}" reached
 - Mov_{Out}: position-controlled movement Ctrl_p → to the end position Lim_{Out}
 - Mov_{Imp}: position-controlled travel Ctrl_p → to the intermediate position Lim_{Imp} (IO-Link only)


Start_{In} positioning task to the end position Lim_{in}



Start_{Out} positioning task to the end position Lim_{Out}


















Start_{Imp} positioning task to the intermediate position Pos_{Imp} (IO-Link only)



10.4 HMI display and control elements

The HMI display and control elements can be used to perform the following functions in the HMI menu:

- Unlock pushbutton actuators (Unlock HMI), press and hold for 3 s  — an active positioning task in DIO or IO-Link mode is stopped
(Condition for IO-Link operation: IO-Link parameter 0x000C.4 = false)
- Select menu function with pushbutton actuators   (selecting menu), press 
- Parameterise Speed Out, Speed In and Force setpoint values
(Set value: 10, 20, ..., 100% of the maximum value  15 Technical data) and save (Save), press 
- Parameterise the position of the reference end position "Ref" (Set Ref) and run the referencing movement Mov_{Ref} (Start_{Ref}: Pos_{Act}  Lim_{In}  Lim_{Out}), press 
- Run Start Press movement (Start/Stop) and save Start Press Position Pos_{Start Press} (Save), press 
- Execute demo run (Start/Stop)
- Lock pushbutton actuators (Lock HMI), press and hold for 3 s  or no pushbutton actuator input for 15 s
- To acknowledge an error, press and hold  for 3 s
- Reset to factory settings, press ,  and  simultaneously for 10 s and then carry out a Power OFF/ON on the logic power supply 24 V DC [pin 1].

Operation




Fig. 7: HMI menu

10.5 Homing with end position determination

WARNING

Risk of injury due to unexpected movement of components.

When starting the homing run, the drive is disconnected from the power supply for a short time. This can cause unexpected movements of the connected mechanics and crush parts of the body.

- Bring moving parts of the connected mechanical system into a safe position.

i

- Referencing with end position determination is only required again if the reference end position "Ref" or the useful range needs to be changed.
- During referencing with end position determination the intermediate position Pos_{Imp} and the start press position $Pos_{Start Press}$ is set equal to the new end position Lim_{Out} .

During referencing with end position determination the positions of the mechanical stops $Mech_{In}/Mech_{Out}$ are recorded in order to calculate the end positions Lim_{In} ("Ref")/ Lim_{Out} for the dimension reference system.

Before running homing with end position determination to a new reference end position "Ref", the drive is de-energised for a required re-initialisation. Then the power is restored and the process is started.

Activating homing with end position determination Start_{Ref}	
Factory setting: left reference end position "Ref"	
<ul style="list-style-type: none"> - HMI: activate "Reference" menu, parameterise reference end position "Ref" and initiate homing → 10.4 HMI display and control elements - IO-Link, process data: parameterise reference end position "Ref" 0x0103.0, false (factory setting) or true and initiate homing 0x0104.0 = true - IO-Link, system parameters: 0x0002, value = 0xCE (Execute "Reference" Movement (False), factory setting) or value = 0xCF (Execute "Reference" Movement (True)) 	
Sequence	
<p>The diagram shows the homing with end position determination</p> <ul style="list-style-type: none"> - Mov_{Ref}: force-controlled movement Ctrl_f → against mechanical stop "Mech_{In}" - Mov_{Out}: position-controlled movement Ctrl_p → to the reference end position "Ref" - Mov_{Ref}: force-controlled movement Ctrl_f → against the mechanical stop "Mech_{Out}" - Mov_{Out}: position-controlled movement Ctrl_p → to the end position Lim_{Out} 	

Tab. 10: Homing sequence with reference end position "Ref" initialisation and end position determination

10.6 Point-to-point operating modes



Automatic saving of device data

If automatic storage is activated (0x0109.0 = true, default), parameter changes in the device data (= data storage parameters → "Integrated drive EMCS" instruction manual → www.festo.com/sp) are made automatically and permanently saved in the flash memory. Exceeding the maximum permissible 100,000 write cycles results in irreparable damage to the flash memory and the device, e.g. when using the device for positioning tasks via IO-Link.

If automatic saving is deactivated (0x0109.0 = false), parameter changes are only temporarily stored in the RAM. The RAM permits an unlimited number of parameter changes, e.g. for positioning tasks via IO-Link.

For simple point-to-point operation the drive can be traversed to the "end positions" $\text{Lim}_{\text{In}}/\text{Lim}_{\text{Out}}$ and intermediate position Pos_{Imp} target positions (IO-Link only).

Point-to-point operation				
Parameterising point-to-point operation				
HMI: – Speed Out, Speed In, Force and Start Press → 10.4 HMI display and control elements IO-Link (acyclic device data): – Speed Out speed: $0x0101.0$, Speed Out ¹⁾ – Speed In speed: $0x0100.0$, Speed In ¹⁾ – Force/torque: $0x0102.0$, force ¹⁾²⁾ – Start Press Position $\text{Pos}_{\text{Start Press}}$: $0x0105.0$, Position Start Press [mm] ²⁾³⁾⁴⁾ – End position Lim_{Out} : $0x0106.0$, end position Out [mm] ⁴⁾ – Intermediate position Pos_{Imp} : $0x0108.0$, Intermediate Position [mm] ³⁾⁴⁾				
Controlling point-to-point operation via digital inputs				
Positioning task	Control signals			
	Mov _{In} DI1 [Logic, Pin 5]		Mov _{Out} DI2 [Logic, Pin 6]	
Start _{In} /Mov _{In}	1		0	
Start _{Out} /Mov _{Out}	0		1	
Stop ⁵⁾	0		0	
Switch off power stage ⁶⁾	1		1	
Control point-to-point operation via IO-Link				
Positioning task	Process parameters			System parameters
	Move "In"	Move "Out"	Move "Intermediate"	System commands
	$0x0029.1$	$0x0029.2$	$0x0029.5$	$0x0002$
Start _{In} /Mov _{In}	true	false	false	= $0xC8$, execute "Move _{In} "
Start _{Out} /Mov _{Out}	false	true	false	= = $0xC9$, execute "Move _{Out} "
Start _{Imp} /Mov _{Imp}	false	false	true	= $0xD0$, execute "Move _{Intermediate} "
Stop ⁵⁾	false	false	false	= $0xCA$, stop motion
Switch off power stage ⁶⁾	≥ 2 x true			= $0xCB$, disable power stage


Point-to-point operation

Sequence


The diagrams show the movements in point-to-point operation

- Mov_{Out}: position-controlled movement Ctrl_p → to the end position "Lim_{Out}"
- Mov_{In}: position-controlled movement Ctrl_p → to the end position "Lim_{In}"
- Mov_{Imp}: position-controlled movement Ctrl_p → to the intermediate position "Pos_{Imp}"
- Point-to-point operation with press function, from Start Press Position "Pos_{Start Press}"
 - Mov_{Out}: force-controlled movement Ctrl_F → until the parameterised force or torque setpoint value "Force" is reached or to the end position "Lim_{Out}"
 - Mov_{Imp}: force-controlled movement Ctrl_F → to the intermediate position "Pos_{Imp}" (IO-Link only)


Simple point-to-point operation



Simple point-to-point operation with intermediate position (IO-Link only)



Point-to-point operation with press function



11 Maintenance

11.1 Safety

WARNING

Unexpected movement of components.

Injury due to impacts or crushing.

- Before working on the product, switch off the control and secure it to prevent it from being switched back on accidentally.

11.2 Cleaning


Clean the product with a clean, soft cloth and non-abrasive cleaning agents.

12 Malfunctions

Acknowledge error

With error acknowledgment, active error messages are deleted from the diagnostic memory if the cause of the error was remedied before acknowledgment.

Errors can be acknowledged via the following interfaces:

- Restart:
 - Logic voltage L+, Power OFF/ON [Logic, Pin 1]
- HMI:
 - Press and hold  for 3 s
- DIO, digital inputs:
 - DI1 "Mov_{In}" and DI2 "Mov_{Out}" = 1 [Logic, Pin 5/6]
- IO-Link, device data:
 - 0x0107.0 Quit Error = true
- IO-Link, process data:
 - 0x0029.3 Quit Error = true
 - 0x0029.1 and 0x0029.2 = true, 0x0029.5 = any

Diagnostic messages and fault clearance

"Information, Warnings and Errors" diagnostic messages are displayed by the C/Q LED and menu and parameters LED displays.

Errors are reported to the controller as follows:

- DIO operation: output signals DO1 and DO2 = 1 [Logic, Pin 2/3]
- IO-Link operation: ProcessDataInput state "In" (0x0028.1) and state "Out" (0x0028.2) = true

i

The first error that occurred is always displayed.




Fig. 8: Display of diagnostic messages (example)

Error code	Description	LED	LED displays	Event code
hex (dec)		C/Q	Menu	Parameter (IO-Link)
Warning				
-	Warnings ¹⁾	yellow light	-	0x...
Errors				
-	Common device error or unlisted errors	red light	...	0x1000
	Remedy - Contact Festo			
0x000F (15)	I ² t monitoring output stage error limit			0x1805
	Remedy -			
0x0016 (22)	Undervoltage in logic supply 24 V ²⁾			0x1804
	Remedy - Check logic voltage supply			
0x0017 (23)	Overvoltage in logic supply 24 V			0x1803
	Remedy - Check logic voltage supply			

Malfunctions

Error code hex (dec)	Description	LED	LED displays		Event code (IO-Link)				
			Menu	Parameter					
0x001F (31)	Undervoltage in intermediate circuit				0x180 6				
	Remedy – Check the load voltage supply – Check power socket for contamination								
0x0026 (38)	Undervoltage in load supply 24 V								0x180 2
	Remedy – Check the load voltage supply – Check power socket for contamination								
0x0027 (39)	Overvoltage load supply 24 V								
	Remedy – Check the load voltage supply								
0x0031 (49)	Temperature in device too low				0x400 0				
	Remedy – Check ambient conditions								
0x0033 (51)	Temperature in device too high								
	Remedy – Check ambient conditions – Check installation conditions								

Error code	Description	LED	LED displays		Event code (IO-Link)
			Menu	Parameter	
hex (dec)		C/Q			
0x012F (303)	IO-Link connection interrupted IO-Link connection interrupted Remedy – Check power supply – Check IO-Link master				–

1) Additional information → Instruction manual for integrated drive EMCS-ST

2) This error can only be acknowledged by a restart.

Tab. 12: "Information, Warnings and Errors" diagnostic messages

12.1 Fault clearance

Fault description	Cause	Remedy
Loud running noises or vibrations or rough running of the rotary drive	Torsional stresses	Change the layout of the attachment component (e.g. payload).
		Change the travel velocity.
Rotating plate does not move	Loads too high	Reduce forces and torques. Consider dynamics.

Tab. 13: Fault clearance

12.2 Repair

Repair or maintenance of the product is not permissible.

- Send product to Festo repair service.
- Replace with an identical product → www.festo.com/spareparts.

13 Replacement

1. Save the application parameters to the IO-Link master → "Integrated drive EMCS" instruction manual → www.festo.com/sp.
2. Demount the drive system → 14 Removal.
3. Mount the drive system → 7 Assembly.
4. Connect the drive system → 8 Installation.
5. Commission the drive system → 9 Commissioning.
6. Update the firmware → "Integrated drive EMCS" instruction manual → www.festo.com/sp.
7. Check the current status of the application data → "Integrated drive EMCS" instruction manual → www.festo.com/sp.

14 Removal

WARNING

Unexpected movement of components.

Injury due to impacts or crushing.

- Before working on the product, switch off the control and secure it to prevent it from being switched back on accidentally.

WARNING

Risk of Injury due to Unexpected Movement of Components

For vertical or slanted mounting position: when power is off, moving parts can travel or fall uncontrolled into the lower end position.

- Bring moving parts of the product into a safe end position or secure them against falling.

Demounting drive system


1. Allow the product to cool down to room temperature.
2. Disconnect electrical installations.
3. Remove the mounted attachment component.
4. Remove the attached accessories.
5. Remove the mounting attachments.
6. Observe transport information → 6 Transport.

Demount drive or integrated drive EMCS → Manual integrated drive EMCS.

15 Technical data

ERMS	-25	-32
Certificates, declaration of conformity for EMCS-ST	→ www.festo.com/sp	
Design	Electromechanical rotary drive with integrated drive	
Rotation angle [°]	90, 180	
Gear ratio	9:1	7:1
Mounting position	Any	
Relative humidity [%]	0 ... 85, non-condensing	
Ambient temperature [°C]	0 ... +50	
Storage temperature [°C]	-20 ... +60	
Degree of protection	IP40	
Maximum speed ¹⁾ [rpm]	150	100
Velocity "Speed Press/Speed Ref" [rpm]	3	2
Max. torque ²⁾³⁾ [Nm]	2.7	5.6

Technical data

ERMS		-25	-32
Max. torque on external stops during referencing ⁴⁾	[Nm]	0.45	1.05
Max. acceleration/deceleration ⁵⁾	[rad/s ²]	140	
Permissible mass moment of inertia	[kgcm ²]	65	164
Duty cycle	[%]	100 (+30 ... +50 °C: -2% per Kelvin)	
Distance between stop and end position ⁶⁾	[°]	2	
Repetition accuracy	[°]	±0.05	±0.1
Nominal voltage	[V DC]	24	
Logic current consumption (logic, pin 1)	[A]	DIO operation: 0.1 ... 0.3 IO-Link operation: 0.1 ...0.15	
Load current consumption (power, pin 1)	[A]	3	5.3
IO-Link port class		A	
IO-Link protocol version		Device V 1.1	
Max. permissible forces and torsional backlash on the rotating plate			
F _x	[N]	350	450
F _y	[N]	450	550
F _z	[N]	450	550
Torsional backlash	[°]	0.2	
			

1) Maximum value for Speed In/Speed Out at level 10

2) Maximum value for Force at level 10

3) Force is controlled and evaluated by closed-loop control of the motor current. Depending on the mechanism of the drive, a torque level can be determined from the level of current measured. The target is set as a percentage of the rated motor current and may differ from the actual force at the rotary drive. At the lower force levels the frictional force of the drive system may be greater than the set feed force and may result in the drive system coming to a standstill.

4) The torque acts on the stop for ≤100 ms

5) Parameter that cannot be changed.

6) Distance (MechIn – LimIn or MechOut – LimOut)

Tab. 14: Technical data ERMS

Copyright:
Festo SE & Co. KG
Ruiter Straße 82
73734 Esslingen
Germany

Phone:
+49 711 347-0

Internet:
www.festo.com