

#### AVENTICS ED07 Dynamic Direct Acting Pressure Regulator

The AVENTICS Series ED07 offers proportional pressurization and the exhaust valves are controlled separately to deliver dynamic control for the most demanding applications. Highly dynamic proportional pressure regulator Stackable with base plate Nominal width 7 Flow 1300 I/min Pressure range -1 ... 20 bar EtherCAT, AES fieldbus connection





#### Technical data Control Control Function Actual output value Min. regulation range Max. regulation range Min. working pressure Max. working pressure Hysteresis Medium Nominal flow Qn Min. ambient temperature Max. ambient temperature Min. medium temperature Max. medium temperature Operational voltage DC Max. current consumption Protection class Permissible ripple

Directly controlled Analog Air exhaust Analog 0 bar 2 bar 0.5 bar 3 bar < 0,015 bar Compressed air 1300 l/min 5°C 50 °C 5°C 50 °C 24 V 1400 mA IP65 5%



## E/P pressure regulator, Series ED07

R414009634

Max. particle size Min. oil content of compressed air Max. oil content of compressed air Type Mounting orientation Certificates Electrical connection size Signal connection Signal connection Signal connection	50 $\mu$ m 0 mg/m <sup>3</sup> 1 mg/m <sup>3</sup> Poppet valve $\alpha = 0 \dots 90^{\circ} \pm \beta = 0 \dots 90^{\circ}$ CE declaration of conformity via signal connection input and output Plug M12 5-pin
5	U U
0	
Actual output value	0 20 mA
Nominal input value	0 20 mA
Industry	Industrial
Weight	2.05 kg

#### Material

Housing material

Seal material Part No. Die-cast aluminum Steel, chrome-plated Hydrogenated acrylonitrile butadiene rubber R414009634

#### Technical information

With oil-free, dry air, other installation positions are possible on request.

The protection class is only ensured when the plug is mounted properly. For detailed information, see operating instructions.

The min. control pressure must be adhered to, since otherwise faulty switching and valve failure may result!

The pressure dew point must be at least 15 °C less than ambient and medium temperature and may not exceed 3 °C.

The oil content of compressed air must remain constant during the life cycle.

Use only the approved oils from AVENTICS. Further information can be found in the "Technical information" document (available in https://www.emerson.com/en-us/support).



# E/P pressure regulator, Series ED07

R414009634


## Mounting orientation

$$\beta = \pm 0...90^{\circ}$$



R414009634


#### Dimensions



- Operating pressure
  Working pressure
  Exhaust
  Flat gasket
  Accessories not supplied




#### Flow diagram



Pa = Working pressure


#### Characteristic and pin assignment for voltage control with actual output value



#### 1) Supply Voltage

2) Actual value (pin 4) and target value (pin 2) are related to 0 V. If the supply voltage is switched off, the voltage input value is high-ohmic. Input resistance under supply voltage: 1 M $\Omega$  Voltage output (actual value): external working resistance 10 k $\Omega$  3) The operating voltage must be protected by an external M 2.5 A fuse. Connect the plug via a shielded cable to ensure EMC.


#### Characteristic and pin assignment for current control with actual output value



#### 1) Supply Voltage

2) Actual value (pin 4) and nominal value (pin 2) are related to 0 V (control voltage). Nominal input value current (ohmic load 100  $\Omega$ ). Actual output value (max. total resistance of downstream devices < 300  $\Omega$ ). 3) The operating voltage must be protected by an external M 2.5 A fuse. Connect the plug via a shielded cable to ensure EMC.


# Characteristic and pin assignment for potentiometer control without actual output value



1) Supply Voltage

2) Actual value (pin 2) is related to 0 V. If the supply voltage is switched off, the voltage input value is high-ohmic. Input resistance under supply voltage: 1 M $\Omega$  3) The operating voltage must be protected by an external M 2.5 A fuse. Connect the plug via a shielded cable to ensure EMC.

### Functional diagram



a) Nominal input value b) Actual output value The E/P pressure control valve modulates the pressure corresponding to an analog electrical nominal input value.

1) Operating pressure

2) Working pressure

3) Exhaust

