#### 5610264830

Flow 1300 I/min

# **AVENTICS ED07 Dynamic Direct Acting Pressure Regulator**


The AVENTICS Series ED07 offers proportional pressurization and the exhaust valves are controlled separately to deliver dynamic control for the most demanding applications.

Highly dynamic proportional pressure regulator Stackable with base plate

Nominal width 7

Pressure range -1 ... 20 bar EtherCAT, AES fieldbus connection





#### Technical data

Control Directly controlled

Control Analog

Function Air exhaust

Actual output value Analog

Switch output

Min. regulation range0 barMax. regulation range6 barMin. working pressure0.5 barMax. working pressure8 bar

Hysteresis < 0,03 bar

Medium Compressed air

Nominal flow Qn 1300 I/min

Min. ambient temperature 5 °C

Max. ambient temperature 50 °C

Min. medium temperature 5 °C

Max. medium temperature 50 °C

Operational voltage DC 24 V

Max. current consumption 1400 mA
Protection class IP65
Permissible ripple 5%



# E/P pressure regulator, Series ED07

2024-02-20

5610264830

Max. particle size50 μmMax. oil content of compressed air1 mg/m³TypePoppet valve

Mounting orientation  $\alpha = 0 \dots 90^{\circ} \pm \beta = 0 \dots 90^{\circ}$ Certificates CE declaration of conformity

Electrical connection type Plug
Electrical connection size M12
Electrical connection number of poles 5-pin

Signal connection input and output

Signal connection Socket
Signal connection M12
Signal connection 5-pin
Actual output value 0 ... 10 V
Nominal input value 0 ... 10 V
Industry Industrial
Weight 2.05 kg

#### Material

Housing material Die-cast aluminum

Steel, chrome-plated

Seal material Hydrogenated acrylonitrile butadiene rubber

Part No. 5610264830

#### Technical information

With oil-free, dry air, other installation positions are possible on request.

The protection class is only ensured when the plug is mounted properly. For detailed information, see operating instructions.

Minimum working pressure = [[0.5] bar] + max. required secondary pressure

Additional pressure setting ranges available on request

The min. control pressure must be adhered to, since otherwise faulty switching and valve failure may result!

The pressure dew point must be at least 15 °C less than ambient and medium temperature and may not exceed 3 °C.


The oil content of compressed air must remain constant during the life cycle.

Use only the approved oils from AVENTICS. Further information can be found in the "Technical information" document (available in https://www.emerson.com/en-us/support).


5610264830

# Mounting orientation

 $\beta = \pm 0...90^{\circ}$ 



## **Dimensions**




- 1) Operating pressure
- Working pressure
   Exhaust
- 4) Flat gasket
- 5) Accessories not supplied




5610264830

### Flow diagram




Pa = Working pressure

Fig. 3 Characteristic and pin assignment for potentiometer control without actual output value




- 1) Supply Voltage
- 2) Switch output (pin 1) and nominal value (pin 2) are related to 0 V.
- 3) Potentiometer control (min. 0-2 k $\Omega$ , max. 0-10 k $\Omega$ )
- 4) The operating voltage must be protected by an external M 2.5 A fuse Connect plug X2M via a shielded cable to ensure EMC. A) Plug X1S B) Plug

Fig. 2 Characteristic and pin assignment for voltage control with actual output value




- 1) Supply Voltage
- 2) Switch output (pin 1) and nominal value (pin 2) are related to 0 V.
- 3) Actual value (pin 4) is related to 0 V (min. load resistance 1  $k\Omega$ ).
- 4) The operating voltage must be protected by an external M 2.5 Å fuse. Connect plug X2M via a shielded cable to ensure EMC. A) Plug X1S B) Plug

Fig. 1 Characteristic and pin assignment for current control with actual output value



- 1) Supply Voltage
- 2) Switch output (pin 1) and nominal value (pin 2) are related to 0 V. Input current nominal value (ohmic load 100  $\Omega$ ).
- 3) Actual value (pin 4) is related to 0 V (max. total resistance of downstream devices < 300  $\Omega$ ).
- 4) The operating voltage must be protected by an external M 2.5 A fuse. Connect plug X2M via a shielded cable to ensure EMC. A) Plug X1S B) Plug

## Functional diagram



- a) Nominal input value b) Actual output value c) Switch output (acknowledge signal) The E/P pressure control valve modulates the pressure
- 3) Exhaust