Industrial shock absorber, Series SA2-RT

R412010701 2023-10-25

AVENTICS Series SA2 Industrial shock absorbers

The AVENTICS Series SA2 industrial shock absorbers were created for AVENTICS actuators. They Series SA2 decelerate reliably moving masses and thereby increase process speed, production quality, the service life of production facilities and reduce operating noise.





Technical data

Max. impact speed

Mounting Weight

Industry	Industrial
Туре	SA2-RT
Mounting thread	M20x1,5
Stroke	13 mm
Max. energy absorption/stroke	65 Nm
Max. energy absorption/hour	52000 Nm
Cushioning	self-compensating
Medium	Oil
Min. ambient temperature	-10 °C
Max. ambient temperature	60 °C
Effective mass m _e min.	7.5 kg
Effective mass m _e max.	36 kg
Min. return spring force	12 N
Max. return spring force	23 N
Min. impact speed	1.9 m/s

4.2 m/s Lock nut

0.15 kg

Industrial shock absorber, Series SA2-RT

R412010701 2023-10-25

Material

Material cylinder tube Steel, chrome-plated

Surface cylinder tube bronzed

Material piston rod Stainless Steel


Surface piston rod hardened

Material lock nut Steel, chrome-plated

Surface lock nut bronzed

Part No. R412010701

Dimensions




H = stroke

A = mounting thread

Part No.	Туре	Mount- ing thread	ØB	D		Н	K		SW
R412010695	SA2-RT	M12x1	4	2.5	4	10	15	52	14
R412010696	SA2-RT	M12x1	4	2.5	4	10	15	52	14
R412010697	SA2-RT	M12x1	4	2.5	4	10	15	52	14
R412010698	SA2-RT	M14x1,5	4	2.5	5	14	18.5	69	17
R412010699	SA2-RT	M14x1,5	4	2.5	5	14	18.5	69	17
R412010700	SA2-RT	M14x1,5	4	2.5	5	14	18.5	69	17
R412010701	SA2-RT	M20x1,5	6	2.5	6	13	18	75	24
R412010702	SA2-RT	M20x1,5	6	2.5	6	13	18	75	24
R412010703	SA2-RT	M20x1,5	6	2.5	6	13	18	75	24

R412010701 2023-10-25

Cushioning diagram Ø 63 mm



V = velocity [m/s]


M = moving mass

S = soft

M = medium

H = hard

Cushioning diagram Ø 50 mm



V = velocity [m/s]


M = moving mass

S = soft

M = medium

H = hard

Cushioning diagram Ø 40 mm




V = velocity [m/s]

M = moving mass

S = soft

M = medium H = hard Cushioning diagram Ø 32 mm



V = velocity [m/s]

M = moving mass

S = soft


M = medium

H = hard

Industrial shock absorber, Series SA2-RT

R412010701 2023-10-25

Cushioning diagram Ø 25 mm



V = velocity [m/s]


M = moving mass

S = soft

M = medium

H = hard

Cushioning diagram Ø 16 mm



V = velocity [m/s]

M = moving mass

S = soft

M = medium

H = hard