
### Industrial shock absorber, Series SA2-RT

**R412010696** 2023-10-25

## **AVENTICS Series SA2 Industrial shock absorbers**

The AVENTICS Series SA2 industrial shock absorbers were created for AVENTICS actuators. They Series SA2 decelerate reliably moving masses and thereby increase process speed, production quality, the service life of production facilities and reduce operating noise.





#### Technical data

Industry	Industrial			
Type	SA2-RT			
Mounting thread	M12x1			
Stroke	10 mm			
Max. energy absorption/stroke	14 Nm			
Max. energy absorption/hour	30000 Nm			
Cushioning	self-compensating Oil -10 °C			
Medium	Oil			
Min. ambient temperature	-10 °C			
Max. ambient temperature	60 °C			
Effective mass m <sub>e</sub> min.	1.5 kg			
Effective mass m <sub>e</sub> max.	7.7 kg			
Min. return spring force	3.5 N			
Max. return spring force	7 N			
Min. impact speed	1.9 m/s			
Max. impact speed	4.3 m/s			
Mounting	Lock nut			
Weight	0.04 kg			

### Industrial shock absorber, Series SA2-RT

R412010696 2023-10-25

#### Material

Material cylinder tube Steel, chrome-plated

Surface cylinder tube bronzed

Material piston rod Stainless Steel


Surface piston rod hardened

Material lock nut Steel, chrome-plated

Surface lock nut bronzed

Part No. R412010696

#### **Dimensions**




H = stroke

A = mounting thread

Part No.	Туре	Mount- ing thread	ØB	D		Н	К		SW
R412010695	SA2-RT	M12x1	4	2.5	4	10	15	52	14
R412010696	SA2-RT	M12x1	4	2.5	4	10	15	52	14
R412010697	SA2-RT	M12x1	4	2.5	4	10	15	52	14
R412010698	SA2-RT	M14x1,5	4	2.5	5	14	18.5	69	17
R412010699	SA2-RT	M14x1,5	4	2.5	5	14	18.5	69	17
R412010700	SA2-RT	M14x1,5	4	2.5	5	14	18.5	69	17
R412010701	SA2-RT	M20x1,5	6	2.5	6	13	18	75	24
R412010702	SA2-RT	M20x1,5	6	2.5	6	13	18	75	24
R412010703	SA2-RT	M20x1,5	6	2.5	6	13	18	75	24

R412010696 2023-10-25

## Cushioning diagram Ø 63 mm



V = velocity [m/s]


M = moving mass

S = soft

M = medium

H = hard

# Cushioning diagram Ø 50 mm



V = velocity [m/s]


M = moving mass

S = soft

M = medium

H = hard

## Cushioning diagram Ø 40 mm




V = velocity [m/s]

M = moving mass

S = soft

M = medium H = hard Cushioning diagram Ø 32 mm



V = velocity [m/s]

M = moving mass

S = soft


M = medium

M = medi H = hard

### Industrial shock absorber, Series SA2-RT

R412010696 2023-10-25

# Cushioning diagram Ø 25 mm



V = velocity [m/s]


M = moving mass

S = soft

M = medium

H = hard

# Cushioning diagram Ø 16 mm



V = velocity [m/s]

M = moving mass

S = soft

M = medium

H = hard